

# Get a grip on your valve

With our new tool for fast and easy maintenance

## Your Benefits

- **Easy to handle**  
Simple setup, lightweight design
- **One tool for all**  
Suitable for the entire 5-series Diaphragm Valves
- **Material friendly**  
Enables safe operation without metal-plastic contact
- **Flexible**  
Wide adjustment range and simple positioning
- **Tight grip**  
Due to the special non-slipping nylon strap
- **No damage on the valve housing**  
Centric prism layer



## The must-have tool for your Diaphragm Valves

EasyGrip (Mat.No.198.154.019) is a solid and reliable belt wrench for tightening / loosening round threaded joints.

This tool is suitable for (un-)locking the valve housing nut of your GF Diaphragm Valves, making a fast maintenance possible.

EasyGrip is applicable for all dimensions (1/2"-2") of the entire Diaphragm Valve range:

- for manual Diaphragm Valves 514, 515, 517, 519
- as for the DIASTAR product line

Size: 343 x 99 x 43 mm

Weight: 1 kg

## How to use our new tool for the maintenance of your Georg Fischer diaphragm valves:

### 1. Preparation

#### Manual Valves and DIASTAR (FO + DA)

Put the belt around the valve housing, and pull it tight manually.

DIASTAR FC: Before opening the housing, apply operating pressure to put the valve in open position.



### 2. Fasten

Clamp on the buckle. Rotate the knob at the handle clockwise to fasten the belt.



### 3. Open the valve housing

Use the handle as a wrench to loosen the valve housing nut counter-clockwise. Thus maintenance is possible.

#### **Close the valve housing**

Use the handle as a wrench to tighten the valve housing nut clockwise. Mind the marks on the base of valve housing (fig. A)



(fig. A)

### 4. Release belt wrench

After finishing, unlock the tightening knob, loosen the buckle clamp, and remove the belt.

